ResponseCard LT®

The ResponseCard LT is an audience response device used when a presenter wants to gather immediate feedback from the audience.

CHANGING THE CHANNEL

1. Press the **Channel** button.

2. Enter the **two-digit** channel number.   i.e. 11 or 52

   NOTE: Channel numbers can only contain numbers 1 - 5.

3. Press the **Channel** button. A green flash indicates the channel was successfully changed.

RESPONDING

- A green flash indicates that the response was received.

- Two red flashes indicate that the answer choice was invalid.

- A single yellow flash indicates that polling is closed.

- Multiple yellow flashes indicate that the response is sending.

- Multiple yellow flashes followed by a red flash indicate that the response was not received.