

# NovoCast

Wireless Presentation & Collaboration System




## QUICK START GUIDE

To learn more, please visit [www.vivitekcorp.com](http://www.vivitekcorp.com) for user manuals, software, training videos, and more.

# PACKAGE CONTENTS

1



NovoCast

2



Antenna

3



HDMI-to-HDMI Cable

4



USB-to-DC-in Power Cable

5




Wall Mount

6




USB Power Adapter

7




USB-to-Ethernet Adapter

# NovoCast OVERVIEW




- 1 DC 5V Power-in Jack
- 2 Antenna Connector
- 3 HDMI Port
- 4 USB Port
- 5 Audio-out, 3.5mm Jack
- 6 Reset Button



- 7 MicroSD Card Slot

# NovoCast OVERVIEW

---



## SETTING UP NovoCast

---

### Hardware Installation

**HDMI Port:** Connect to a projector.

**USB Port:** Connect to a USB flash drive, mouse or keyboard.

### Power Input


**DC 5V Power Jack:** Connect to the USB power adapter using the supplied USB cable.

# SETTING UP NovoCast

## WiFi Setup

There are two ways to connect to NovoCast:

### Hotspot Mode



NovoCast's default setting is set to Hotspot mode. The connection is made directly to the SSID broadcasted by the device.

### Wireless AP Mode



NovoCast can also be connected to an existing WiFi network simply by connecting the devices to the same network. Tap the WiFi button to proceed.



# GETTING STARTED

## 1 Install the app.

- For tablet/smartphone: Download *NovoPresenter* from the iOS App Store or from Google Play.



- For Windows/Mac computer: Download *Desktop Streamer* from the Vivitek website ([www.vivitekcorp.com](http://www.vivitekcorp.com)).



- For Chromebook: Download *Desktop Streamer* from the Chrome Web Store.



chromebook

## 2 Connect the tablet/smartphone, computer or Chromebook to the same network as the NovoCast. Follow the device's WiFi procedures for connecting to the WiFi network.

## 3 Launch *NovoPresenter* or *Desktop Streamer*.

- 4 Scan the QR code or manually input the device's IP address and PIN code (if needed) to connect.  
The device screen will appear automatically upon successful connection.



# SCREEN MIRRORING

NovoCast supports direct mirroring of Android™ and iOS device screens.



- 1 Connect the Android™ or iOS device to the same WiFi network as the NovoCast. Then, follow the mirroring setup instructions for the selected Android™ or iOS device.
  - For Android devices, this is referred to as Miracast®, Screen Mirroring, Cast Screen, etc.
  - For iOS devices, this is called AirPlay®.

# ADDITIONAL INFORMATION

---

## Safety & Warning Information

### FCC – Federal Communication Commission (USA)

This device contains the following wireless device and underwent the certification process of FCC 47 CFR PART 15 SUBPART C/E under the respective FCC ID below:

- FCCID: H79-18D7EA3

The FCC ID is indicated as the label affixed on the bottom side of your device.

### CE - Conformité Européenne (EU)

This device intended for sale within the European Union are marked with the Conformité Européenne (CE) Marking, which indicates compliance with the applicable Directives and European Norms, and amendments, the following standard were applied:

- EN55022/24:2010
- EN301 489-1 V1.9.2 (2011-09)
- EN301 489-17 V2.2.1 (2012-09)
- EN300 328 V1.9.1 (2015-02)
- EN301 893 V1.7.1:2012
- EN62311:2008
- EN60959-1:2006+A11:2009+A1:2010+A12:2011+A2:2013



# CONTACT INFORMATION

---

## **Vivitek U.S.A. Corporate Office**

46101 Fremont Blvd.

Fremont, CA 94538

Tel: (855) 885-2378

(855) 885-2378x1 - Sales

(855) 885-2378x2 - General Customer Services

(855) 885-2378x3 - Technical Support

## **Vivitek EMEA Headquarters**

Zandsteen 15

2132 MZ Hoofddorp

The Netherlands

Customer Service & Technical Support:

Monday - Friday 09:00 - 18:00

English (UK): 0333 0031993

Germany: 0231 7266 9190

France: 018 514 8582

International +31 (0) 20 721 9318



Connect | Work | Share

Visit [www.vivitekcorp.com](http://www.vivitekcorp.com) for more product info  
Copyright© 2017 Delta Electronics, Inc. All Rights Reserved.

A brand of  **DELTA**